



HANSABASIC


Installation and maintenance guide



4-9



10,12,
13




11-12



14-19



20



21




22



5535 0110


EN 1111, EN 1112, EN 1113
 100 - 1000 kPa
 0.18 / 0.24 l/s (300 kPa)
 max. +65°C






mpi.hansa.com/55350110

5516 2131

II (ISO 3822)
 EN 1111
 100 - 1000 kPa
 0.16 l/s (Eco)
 0.34 / 0.19 l/s (300 kPa)
 max. +65°C













mpi.hansa.com/55162131















1 3









cleaning.hansa.com