





HANSASTE**LA**



Installation and maintenance guide





5715 2273



I (ISO 3822)
EN 817
50 - 1000 kPa
0.08 l/s (300 kPa)
max. +80°C



mpi.hansa.com/57152273

5767 0173



EN 817
50 - 1000 kPa
max. +80°C






mpi.hansa.com/57670173

5774 2173


I (ISO 3822)
EN 817
50 - 1000 kPa
0.212 l/s (300 kPa)
max. +80°C






mpi.hansa.com/57742173



max.
1600 kPa







2.5

②



⑤ ⑥

