



Spare Parts / Ersatzteile / Pièces de recharge / Pezzi di Ricambio / Piezas de requesto /
Parte de reposição / Reserveonderdelen / Reservdelar / Reservedeler / Varaosat /
Vraosat / Varahlutir / Ανταλλακτικά / Yedek Parçalar / Náhradní díly / Náhradné diely /
Nadomestni deli / Резервни части / Запчасти / Części Zapasowe / Piese de schimb /
Rendelhető alkatrészek / Запасні частини / Reservní delovi / Резервни делови /
Резервни делови / Atsarginių dalių / Tellitavad varuosad / Rezervju daju

XX = AA, AD...

Position


- 1 = A 962040 XX
2 = A 962041 NU
4 = A 962042 XX
5 = A 961667 NU (2x)
7 = A 860114 NU
8 = A 961335 NU
9 = A 963154 NU
11 = A 963309 NU
13 = A 962043 NU
15 = A 960001 NU
16 = A 962044 XX
18 = A 962045 NU
19 = A 962370 NU
20 = A 963404 NU
21 = A 961230 XX
23 = A 960019 XX
24 = B 964902 XX
25 = A 960196 NU



MELANGE

A 4258 .. A 4260 .. A4268 .. A4287 ..

0811/ A 865 736
(+ A 865 612)



Ideal Standard International BVBA
Chaussée de Wavre, 1789 - box 15
1160 Bruxelles
Belgium

www.idealstandardinternational.com

