



HANSA

Installation and maintenance guide



4-9



10-11




12-19



20-22



22-25



26-29




30



6514 0201


I (ISO 3822)
EN1111
100 - 1000 kPa
0.12 l/s (Eco)
0.22 l/s (300 kPa)
250 kPa (0.2 l/s)
max. +80°C



mpi.hansa.com/65140201

6513 2201



I (ISO 3822)
EN1111
100 - 1000 kPa
0.32/0.22 l/s (300 kPa)
265 kPa (0.3 l/s)
max. +80°C







mpi.hansa.com/65132201



4813 0331




I (ISO 3822)
EN1111
100 - 1000 kPa
0.12 l/s (Eco)
0.22 l/s (300 kPa)
250 kPa (0.2 l/s)
max. +80°C










mpi.hansa.com/48130331























①



cleaning.hansa.com