



Ordering spares / Ersatzteil - Regelung / Pièces de rechange / Parti di ricambio / Lista de recambios / Onderdelen bestellen (NL/B) / Κωδικοί Ανταλλακτικών / Bestilling af reservedele / Beställning av reservdelar / Bestilling av reservedeler / Резервни части / Запчасти / Części zapasowe / Piese de schimb / Rendelhető alkatrészek / Запасні частини / Резервни делови / Резервни делови / Atsarginių dalių / Tellitavad varuosad / Rezerves daļas / Náhradní díly / Náhradné diely / Yedek parça siparişi / Nadomestni deli

XX = AA, AD,

- 1 - B 961666 XX
- 3 - B 960473 AA
- 4 - B 961373 XX
- 5 - B 961374 NU
- 6 - A 861181 NU
- 7 - A 861156 NU
- 11 - A 960944 NU
- 12 - A 962574 NU
- 13 - B 960255 NU
- 14 - A 963600 NU
- 15 - B 961119 XX
- 17 - A 962991 AA
- 18 - A 960911 NU
- 19 - A 963807 NU
- 20 - B 961667 XX
- 21 - B 960754 XX




concept


concept 200


12.2019 / B665921

B C586 ..




ISG Sanitär-Handelsgesellschaft mbH & Co. KG
Berthold-Beitz-Boulevard 461
DE 45141 Essen





	P	bar		MAX. 10		5			Q (3 bar)
	T	°C		MAX. 80		65			I/min
						40			5



1. Installation of the faucet handle.

2. Installation of the faucet handle.

3. Installation of the faucet handle.

4. Installation of the faucet handle.

5. Installation of the faucet handle.

6. Installation of the faucet handle.

7. Installation of the faucet handle.

8. Installation of the faucet handle.

9. Installation of the faucet handle.

10. Installation of the faucet handle.

11. Installation of the faucet handle.

12. Installation of the faucet handle.

13. Installation of the faucet handle.

14. Installation of the faucet handle.

15. Installation of the faucet handle.

